

## Handheld shower set with slide bar Juego de ducha de mano con barra deslizante

Model number / Número de modelo  
11 3801 \_\_ / 11 3831 \_\_

Series / Serie  
**Esconte / Priani**




3501 Challenger Street, Torrance, CA 90503  
TEL 310.371.8000 FAX 310.303.7999

### Slide Bar


Remove the mounting hardware post from the body base and use it as a reference for positioning.  
Quitar el hardware de montaje del anuncio de la base del cuerpo y lo utilizan como una referencia para el posicionamiento.

#### 1 Installing on Wooden Surface



For wooden surface, the mounting hardware posts can be secured by screwing the screws directly into the wall.  
Para la superficie de madera, los puestos de hardware de montaje se pueden asegurar atornillando los tornillos directamente en la pared.


#### 2 Installing on Drywall



Mark the two screw hole positions by using the mounting hardware post. Using a drill, pre-drill holes for the toggles. Fold the toggle's legs and insert them into the wall. The mounting hardware posts can be secured by screwing the screws into the toggles.

Marque las de dos posiciones de los agujeros de los tornillos utilizando el hardware de montaje posterior. Usando un taladro, agujeros pre-perforados para las palancas. Doblar piernas las palancas acodadas e insertarlos en la pared. Los puestos de hardware de montaje se pueden asegurar atornillando los tornillos en las palancas.


**3** Installing on Solid / Hard Surface



Measure the dimensions carefully. Mark the two screw hole positions by using the mounting hardware post. Using a drill, pre-drill the holes. Insert anchors into the wall. Secure the mounting hardware posts by screwing the screws into the anchors.

Medir las dimensiones cuidadosamente. Marque las de dos posiciones de los agujeros de los tornillos utilizando el hardware de montaje posterior. Usando un taladro, antes de perforar los agujeros. Inserte los anclajes en la pared. Asegure los postes de hardware de montaje atornillando los tornillos en los anclajes.

**4**



**POSITIONING**

Note: Slide bar is most secure when screwing mounting posts into a cross brace or wall stud within the wall. Position the mounting posts on the wall 26-1/2 inches apart from center to center, vertically.

Measure the dimensions carefully. Mark the eight screw hole positions by using the mounting hardware posts.

Follow the steps mentioned on previous page to secure the mounting posts onto the finished wall.

Tighten all eight screws into the mounting posts firmly.

**POSICIONAMIENTO**

Nota: Slide Bar es más segura al atornillar Mensajes de montaje en un soporte o pared de postes cruz dentro de la pared.


Coloque los postes de montaje en la pared 27 pulgadas de distancia de centro a centro, verticalmente.

Medir las dimensiones cuidadosamente. Marque las ocho posiciones de los agujeros de los tornillos utilizando los Montaje Hardware Mensajes.

Siga los pasos mencionados en la página anterior para fijar los postes de montaje en la pared acabada.

Apretie los ocho tornillos en los postes de montaje firmemente.

**5**



**ASSEMBLY (1)**

Note: The slide bar can be mounted with the spray assembly on the right or left side of the adjustable bracket, depending on your preference.

Using the provided allen key, loosen the bar posts' set screws.

Set the bar posts apart from each other onto a flat surface with openings facing each other and insert the sliding bar into both unsecured bar posts.

Make sure the slide bar assembly is fitted together securely.

Lift the slide bar assembly to the wall vertically and align with the mounting posts.

Slip the slide bar assembly over the top and bottom mounting hardware posts.

**ASAMBLEA (1)**

Nota: la barra de desplazamiento se puede montar con la Asamblea del aerosol en el lado derecho o del soporte ajustable a la izquierda, dependiendo de su preferencia.

Utilizando la llave Allen proporcionada, afloje los tornillos puesto el listón de Mensajes.


Puesto el listón Mensajes separados unos de otros sobre una superficie plana con aberturas frente al otro e inserte la barra corrediza en ambas Bar sin garantía Mensajes.

Asegúrese de que el conjunto de la barra de diapositiva está bien coordinado con seguridad.

Levante el conjunto de la barra de diapositiva a la pared vertical y alinee con los postes de montaje.

Deslice el conjunto de la barra de diapositiva en los superiores e inferiores de montaje Hardware Mensajes.

6




Adjust the bar posts if necessary and secure by firmly tightening the set screws with the allen key.

Check both bar posts to make sure they are firmly secured. If not completely secured, tighten the set screw a bit more with the allen key.

Ajuste la barra Mensajes de ser necesario y seguro apretando firmemente los tornillos de fijación con la llave Allen.

Compruebe ambos Bar Mensajes para asegurarse de que están bien sujetos. Si no está completamente asegurado, apriete el tornillo de ajuste un poco más con la llave Allen.

7



Note: Supply elbow is not included (there is a personal preference as to where the water source will come from).

NOTE: ATTACH THE HOSE PROPERLY BY FOLLOWING THE INSTRUCTIONS BELOW.

Attach the hex nut on the hose to the water source. Attach the conical nut at the other end of the hose to the hand shower.

Slip the spray assembly into the slotted groove of the adjustable bracket.

You can now move the adjustable bracket to desired height.


Nota: codo de alimentación no está incluido (hay una preferencia personal en cuanto a donde la fuente de agua provendrá).

NOTA: Conecte la manguera correctamente siguiendo estas instrucciones.

Coloque la tuerca hexagonal en la manguera a la fuente de agua. Coloque la TUERCA CONICA en el otro extremo de la manguera de la ducha de mano.

Deslice el conjunto del aerosol en la ranura ranurada del soporte ajustable.


Ahora puede mover el soporte ajustable a la altura deseada.




ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	V708460	Slide Bar Post	2
2	PM-017	O-Ring	3
3	PM-016	Drywall Screw	8
4	PM-1080	Anchor for Solid Wall	8
5	PM-027	Set Screw	2
6	PM-407	Rubber Washer	2
7	PM-053	O-Ring	2
8	PM-477	Mounting Post	2
9	PM-026	Drywall Toggle	8
10	VHS-400	Handheld Shower	1
11	VHS-450	MF Handheld Shower	1
12	PS200-2	Hose	1
13	SL-700-1	Slide Bar	1
14	SL-700-2	Bracket	1
15	PM-033	Allen Key	1

ARTÍCULO NO.	PARTE NÚMERO	DESCRIPCIÓN	CANT.
1	V708460	Deslice Bar Publicar	2
2	PM-017	O-Ring	3
3	PM-016	Tornillo drywall	8
4	PM-1080	Ancla para Wall Sólido	8
5	PM-027	Juego de tornillos	2
6	PM-407	Arandela de goma	2
7	PM-053	O-Ring	2
8	PM-477	Publicar montaje	2
9	PM-026	Drywall Toggle	8
10	VHS-400	Ducha de mano	1
11	VHS-450	MF Ducha orientable	1
12	PS200-2	Manguera	1
13	SL-700-1	Slide Bar	1
14	SL-700-2	Soporte	1
15	PM-033	Llave Allen	1

11 3801 \_\_



11 3831 \_\_



# VISSONI™

## FINISH CARE INFORMATION

**WARNING:** Do not clean your VISSONI product with ammonia (Window cleaner), bleach, soaps, acids, abrasives, harsh polishes, harsh cleaners, a coarse surfaced cloth, coarse sponge, or any type of scouring pad. Doing so may ruin your faucet finish and/or void the warranty.

Thank you for making VISSONI a part of your lifestyle and luxury spa experience. Our products have been created as works of enduring quality and sophisticated design. Luxurious finishes need proper care and attention, so in order to understand how to properly clean your distinctive luxury finish please refer to the finish care information below:

Your VISSONI product can be identified in one of two categories: clear coated finishes or non-clear coated finishes. Clear coated finishes are more scratch-sensitive and more reactant to harsh cleaning chemicals than non-clear coated finishes. Once you have identified the specific luxury finish of your VISSONI product, please follow the important corresponding care instructions.

## CLEAR COATED FINISHES

### Polished & Satin 24K (Rose) Gold:

The Karat mark states the percentage of pure gold – 24K is 100 percent gold. As one of the Earth's most precious metals, gold is the most supple and malleable of all metals. Gold-plated faucets scratch easily. To clean, wipe down with a dry soft cloth after each use. Gold surfaces should be coated with a thin layer of non-abrasive carnauba wax or liquid car wax up to 3 or 4 times per year. This will prevent water spotting and water deposit buildup. We recommend using VISSONI's Polish which has been formulated to clean and seal, leaving behind a protective coating that will resist tarnishing and improve water repellency.

### Matte Black & Antique Bronze:

Antique bronze simulates the antiquity of Old-World craftsmanship with a golden base color and a blend of dark undertones. To clean, wipe down with a dry soft cloth after each use. They should be coated with a thin layer of non-abrasive carnauba wax or liquid car wax up to 3 or 4 times per year. We recommend using VISSONI's Polish which has been formulated to clean and seal, leaving behind a protective coating that will resist tarnishing and improve water repellency.

### Bright Victorian Bronze & Oil Rubbed Bronze:

Oil-rubbed bronze simulates the antiquity of Old-World craftsmanship with its warm, dark brown color and copper undertones. To clean, wipe down with a dry soft cloth after each use. They should be coated with a thin layer of non-abrasive carnauba wax or liquid car wax up to 3 or 4 times per year. We recommend using VISSONI's Polish which has been formulated to clean and seal, leaving behind a protective coating that will resist tarnishing and improve water repellency.

## NON-CLEAR COATED FINISHES

### Polished Chrome :

Chrome plating is extremely reflective, with a rich bluish luster. To clean, wipe down with a dry soft cloth after each use. A non-abrasive all-metal cleaner can then be applied to restore the shine. The surface can also be coated with a thin layer of non-abrasive carnauba wax or liquid car wax. This will prevent water spotting and water deposit buildup. We recommend using VISSONI's Polish which has been formulated to clean and seal, leaving behind a protective coating that will resist tarnishing and improve water repellency.

### Platinum & Satin Platinum:

Platinum is the most precious of white metals and is over 20 times rarer than gold. It is also very durable and resists tarnishing. To clean, wipe down with a dry soft cloth after each use. A non-abrasive all-metal cleaner can then be applied to restore the shine. The surface can also be coated with a thin layer of non-abrasive carnauba wax or liquid car wax. This will prevent water spotting and water deposit buildup. We recommend using VISSONI's Polish which has been formulated to clean and seal, leaving behind a protective coating that will resist tarnishing and improve water repellency.

If you may have any further questions, comments, or concerns please write to us at [www.info@vissoni.com](mailto:www.info@vissoni.com).

# VISSONI™

## LIFETIME LIMITED WARRANTY

VISSONI is committed to enhancing your bathroom experience by creating luxury products that will provide enduring satisfaction. Every effort has been made to satisfy the highest standards of design and production, to create lasting peace of mind for our customers. We provide the following limited warranties on our products:

## LENGTH OF WARRANTY & WHO IS COVERED BY OUR WARRANTY

This warranty extends to the original consumer purchaser only and extends for as long as the original purchaser owns the product and the home in which the product is installed.

## WHAT IS COVERED BY OUR WARRANTY

### Finishes:

Polished chrome, platinum, and satin platinum finishes carry a lifetime limited warranty against all manufacturer's defects and tarnish. 24k polished (rose) gold, and 24k satin (rose) gold finishes carry a five (5) year limited warranty against all manufacturer's defects and tarnish.

Antique bronze, bright victorian bronze, matte black, and oil-rubbed bronze finishes carry a five (5) year Limited Warranty against all manufacturer's defects and tarnish. There is no warranty on living finishes.

### Mechanical:

A Lifetime Limited Warranty is provided on parts to be free from failure related to defects in materials and workmanship. Vissoni cartridges carry a Five (5) Year Limited Warranty against manufacturer's defects.

## EXCLUSIONS AND LIMITATIONS OF WARRANTY

This warranty does not cover:

1. Damage due to negligence, accident, abuse, improper installation, or improper maintenance such as, but not limited to: heat from soldering during installation, the use of plumber's putty, damage from tools used during installation, the use or exposure to chemicals or cleaning products either abrasive or non-abrasive, or the use of any cleaning tool or product other than a soft, clean cloth. Reverse osmosis may also shorten the life of the finish.
2. Changes in the finish or in the product due to normal wear or aging does not cover any products or parts which have been altered or used in a manner not typical for the product.
3. Loss, damages, or expense, incidental or consequential whatsoever, originating from the purchase, installation, use, repair, failure, or replacement of any VISSONI product or part, allowed by law.
4. Commercial and/or Industrial installations and use of the product.
5. This warranty does not include labor, travel charges, or any costs incurred for repair, removal, installation, servicing, diagnosing, or handling of either defective or replacement parts.
6. Damage or deterioration caused by environmental impacts.

The product or components of the covered product will be repaired, refinished, or replaced, at the sole discretion of VISSONI. VISSONI reserves the right to examine the product claimed defective prior to any warranty claim being accepted or processed, at its sole discretion. This warranty gives you specific legal rights and you may have other rights which may vary from state to state.

## TO OBTAIN WARRANTY SERVICE

Please read 'WHAT IS COVERED BY OUR WARRANTY' and 'EXCLUSIONS AND LIMITATIONS OF WARRANTY' sections to understand what is and what is not covered. Please have ready the proof of purchase (original sales receipt), description of the problem, and carefully package the product or defective part with postage prepaid. Then, please contact your local VISSONI Showroom or write to VISSONI Customer Services.

If you may have any further questions, comments, or concerns please write to us at [www.info@vissoni.com](mailto:www.info@vissoni.com).